

# REMINGTON®

## Flexibrush Steam




**CB4N**

 [www.remington.co.uk](http://www.remington.co.uk)

**Register online for an EXTRA year guarantee**

Visit [uk.remington-europe.com/product-registration](http://uk.remington-europe.com/product-registration) You must register within 28 days of purchase.




Thank you for buying your new Remington® product. Please read these instructions carefully and keep them safe. Remove all packaging before use.

**WARNING: This appliance is hot. Keep out of reach of children at all times.**

---

## IMPORTANT SAFEGUARDS

---

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been supervised/instructed and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be done by children unless they are older than 8 and supervised. Keep the appliance and cable out of reach of children under 8 years.
  -  Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
  - When the appliance is used in a bathroom, unplug it after use since the proximity of water presents a hazard even when the appliance is switched off.
  - For additional protection, the installation of a residual current device (RCD) having a rated residual operating current not exceeding 30 mA is advisable in the electrical circuit supplying the bathroom\*.
- \* Currently, the fitting in a bathroom of an electrical socket suitable or capable of operating the appliance is not permitted in the UK (see BS7671).
- Burn hazard. Keep the appliance out of reach from young children, particularly during use and while cooling down.
  - Never leave the appliance unattended when it is connected to the power supply.
  - Always place the appliance with its stand, if any, on a heat-resistant, stable flat surface.

- If the supply cord of this unit becomes damaged, discontinue use immediately and return the appliance to your nearest authorised Remington® service dealer for repair or replacement in order to avoid a hazard.
- Do not allow any part of the appliance touch the face, neck or scalp.
- Keep the power plug and cord away from heated surfaces.
- Do not use attachments other than those we supply.
- Do not use the appliance if it is damaged or malfunctions.
- Do not twist or kink the cable, or wrap it round the appliance. Check the cord regularly for any sign damage.
- This appliance is not intended for commercial or salon use.

---

## **PARTS**

---

- |                            |                        |
|----------------------------|------------------------|
| 1. Ceramic coated barrel   | 6. On indicator light  |
| 2. Water reservoir         | 7. Curl release button |
| 3. Water level window      | 8. Stand               |
| 4. Bristle lock guard      | 9. Swivel cord         |
| 5. Heat resistant bristles |                        |

---

## **ADDITIONAL FEATURES**

---

- Fast heat up—ready to use in 60 seconds.
- Multivoltage: for home or abroad. At 120V times and temperatures may vary.

---

## **INSTRUCTIONS FOR USE**

---

- Before use, ensure the hair is clean, dry and tangle-free.
  - For extra protection use a heat protection spray.
  - Hairsprays contain flammable material – do not use while using this product.
  - This appliance can be used without steam; when steam is required fill the water reservoir first.
1. Hold the unit in a vertical position with cap end down to prevent any spillage from any residual water left in the cap.
  2. Unscrew the reservoir and fill with warm or cool water to the fill line. Replace the cap with the tong still held vertically with cap end down and twist gently into place.
  3. The water level in the reservoir can be seen through the water level window.
  4. Section the hair prior to styling. Style the lower layers first.
  5. Plug the unit into the mains and wait for it to heat up.

- To activate steam, gently depress the cap. The unit is designed to release with one push, just the right amount of steam required for a small section of hair.
- Take a section of hair and place the ends around the brush. Rotate the styler allowing the hair to wrap around the barrel of the brush.
- Press the reservoir cap to release the steam.
- Wait about 10 seconds for curl to form.
- Press the curl release button and carefully draw the unit away allowing hair to unwind automatically.
- Allow the hair to cool before styling.
- When finished unplug the appliance and allow to cool before cleaning and storing away.

### Changing the Bristles

- To change the bristles, the unit must be unplugged and cool. Remove the reservoir and unscrew the bristle lock guard and slide the bristles off the barrel.
- Taking the other set of bristles, gently glide each row into a groove on the barrel and push into place. Screw the lock guard securely back into place and replace the reservoir.

---

## CLEANING AND MAINTENANCE

---

- Unplug the appliance and allow to cool.
- Wipe all the surfaces with a damp cloth.
- Don't use harsh or abrasive cleaning agents or solvents.

---

## RECYCLING

---



To avoid environmental and health problems due to hazardous substances, appliances and rechargeable and non-rechargeable batteries marked with one of these symbols must not be disposed of with unsorted municipal waste. Always dispose of electrical and electronic products and, where applicable, rechargeable and non-rechargeable batteries, at an appropriate official recycling/ collection point.

---

## SERVICE AND GUARANTEE

---



Defects affecting product functionality appearing within the guarantee period will be corrected by replacement or repair at our option provided the product is used and maintained in accordance with the instructions. Your statutory rights are not affected.

To claim an extra 1 year guarantee, register your product online within 28 days of purchase.

Register at: <https://uk.remington-europe.com/product-registration>

Consumables are guaranteed only for their recommended lifecycle. Replacement/spare parts\* are excluded and are only covered by a 1 year warranty.

\*Examples include, but are not limited to, adaptors, haircare attachments, grooming accessories, etc.

---

## SERVICE CENTRE


---

### United Kingdom

 0800 212 438 (free call mainland UK)

Spectrum Brands (UK) Ltd  
Fir Street, Failsworth, Manchester  
M35 0HS, UK  
[www.remington.co.uk](http://www.remington.co.uk)

### Ireland

 142 951 40

Remington Consumer Products,  
Unit B12, Ballymount Corporate Park,  
Ballymount, Dublin 12  
<https://ie.remington-europe.com>

# Model No. CB4N

19/UK/ CB4N T22-7000657 Version 02 /19

Remington® is a Registered Trade Mark of Spectrum Brands, Inc., or one of its subsidiaries.

Spectrum Brands (UK) Ltd

Fir Street,

Failsworth,

Manchester

M35 0HS

[www.remington.co.uk](http://www.remington.co.uk)

© 2019 Spectrum Brands, Inc.